



**Racing Products Limited**

Rudge  
Church Brampton  
Northampton NN6 8AU  
England  
Tel: (0604) 842320  
Reg. in England No. 2095770  
VAT No. 460 9875 12

S.P.C. INSTRUCTIONS.

(SUPPLEMENTARY TO 'C' CAR INSTRUCTIONS)

ASSEMBLE AS 'C' CAR BUT WITH THE FOLLOWING DIFFERENCES:

PREPARE CHASSIS BY CAREFULLY FILING OFF ALL 'PIPS' AND FILING SMALL CHAMFER ON UPPER SIDE OF BATTERY SLOTS TO ALLOW CELLS TO LIE FLUSH WITH UNDERSIDE OF CHASSIS, FINALLY SMOOTH OF ALL SHARP EDGES USING FINE EMERY, PAYING PARTICULAR ATTENTION TO TAPE SLOTS AND REAR OF CHASSIS TO AVOID CUTTING TAPE RETAINING NICADS.

C113 UPPER CROSS MEMBER REPLACES C040, RADIO TRAY.

USE INTERMEDIATE OR SOFTEST SETTING FOR REAR 'T' PIECE.

IT IS RECOMMENDED THAT NO ITEM IS MOUNTED DIRECTLY ONTO 'T' PIECE, HOWEVER THE SPACE BETWEEN THE NICADS CAN BE UTILISED BY MOUNTING COMPONENT ON 2 SMALL SERVO TAPE PADS EITHER SIDE OF 'T' PIECE, ONTO CHASSIS.

HOLD BATTERIES ONTO CHASSIS USING TAPE, THE BEST TYPE FOR THIS PURPOSE IS GLASS FIBRE REINFORCED, DO NOT TAPE IN BATTERIES TOO TIGHTLY AS THIS MAY CAUSE A 'TWEAK' IN THE CHASSIS.